FOXCOM

Complete RF-2-Fiber Solutions

7225H Interfacility Link
Installation and User's Guide

©Copyright 2003

FOXCOM

Complete RF-2-Fiber Solutions

SATLIGHT

7225H Interfacility Link
Installation and User's Guide

Foxcom Inc.
Princeton Forrestal Village
136 Main Street, Suite 300
Princeton NJ 08540
USA
Tel: 609-514-1800
Toll Free: 1-866-ONEPATH
Fax: 609-514-1881

Foxcom Ltd.
Beck Science Center
8 Hartom Street, Har-Hotzvim
P.O. Box 45092
Jerusalem 91450
Israel
Tel: +972-2-589-9888
Fax: +972-2-589-9898
Website: www.foxcom.com
e-mail: sales@foxcom.com

This manual contains PROPRIETARY and CONFIDENTIAL information of Foxcom Inc. Reproduction, release to any third party, or any other unauthorized use, of any information contained herein is expressly prohibited

Table of Contents

1. Front Chapter 7
1.1. Warranty and Repair Policy 7
1.2. Reporting Defects 9
1.3. Certification 9
1.4. Conventions 9
1.5. Precautions 10
2. Introduction to the 7225H Interfacility Link (IFL) 11
2.1. Options 11
2.2. Product Drawings 13
2.3. Panel Descriptions 14
2.4. Block Diagrams 15
3. Installation 16
3.1. Setting up the Transmitter 17
3.2. Connecting the Fiberoptic Cable 18
3.3. Setting Up the Receiver 19
3.4. Powering the IFL 20
3.5. Connecting the Back Panel Jumpers 21
3.6. Measuring the RF Signal Strength 24
3.7. Aligning the Fiberoptic Link 24
4. Product Specifications 25
4.1. 7225H IFL Specifications 25
4.2. Model Dimensions 27
4.3. 7225H IFL Pinouts 28
4.4. 7180M Chassis Pinouts 32
5. Gain Control 36
6. Troubleshooting 37
7. Appendix 1 Cleaning Fiberoptic Connections 39
7.1. Cleaning Procedures for FC/APC Connectors 40
7.2. Cleaning Procedure for FC/APC Bulkhead Ports 41
8. Appendix II Installing a Standalone Unit 42
9. Appendix III The 2380 Relay Adaptor 43
9.1. Installing the 2380 - Parts Needed 43
9.2. Installing the 2380 - Procedure 43
9.3. 2380 Dimensions and Front Panel Label 45
9.4. 2380 Pinouts 46
10. Appendix IV 7100M Chassis 48
10.1. Equipment Safety 48

10.2. Installation 49
10.3. Model Dimensions 58
10.4. 7225H IFL Pinouts (7100M Chassis) 59
10.5. 7100M Pinouts 63
10.6. The 2300 Relay Adaptor 66
10.7. Changing the Primary Power Setting 72
11. Appendix V Pinouts, Detailed Information 74

List of Figures

Figure 1 - Option Label 12
Figure 2 - 7225HT Transmitter Front and Rear Panel 13
Figure 3 - 7225HR Receiver Front and Rear Panel 13
Figure 4 - Transmitter Block Diagram 15
Figure 5 - Receiver Block Diagram 15
Figure 6 - Typical Application of a 7225H IFL 16
Figure 7 - 7180M Chassis Rear View 21
Figure 8 - Jumper Installation: Tx and Rx Only 22
Figure 9 - Jumper Installation: 2000 Switch in Slot 2 22
Figure 10 - Jumper Installation: 2000 Switch in Slot 5 23
Figure 11 - Jumper Installation: 2000 Switch in Slots 2 and 5 23
Figure 12 - Fiberoptic Alignment Setup 24
Figure 13 - Unit Dimensions 27
Figure 14 - 7180M Chassis Dimension 27
Figure 15 - 7225HT Transmitter Pinout 29
Figure 16 - 7225HR Receiver Pinout 31
Figure 17 - 7180M Chassis Rear View 32
Figure 18 - 7180M Pin Numbers 35
Figure 19 - Wiping the Connector with a Kim Wipe 40
Figure 20 - Wiping the Connector with a Kim Wipe (2) 40
Figure 21 - Cleaning the Optical Port 41
Figure 22 - Cleaning the Optical Port (2) 41
Figure 23 - Mounting the Chassis and Adaptor - Detail 43
Figure 24 - Mounting the Pins and Adaptor 44
Figure 25 - Mounting the Screws (1) 44

Figure 26 - Mounting the Screws (2) 44
Figure 27 - Mounted 2380 45
Figure 28 - 2380 Dimensions 45
Figure 29 - 2380 Front Label 45
Figure 30 - 2380 Pin Numbers 47
Figure 31 - 7100M Chassis Rear View 55
Figure 32 - Jumper Installation: Tx and Rx Only 56
Figure 33 - Jumper Installation: 2000 Switch in Slot 2 56
Figure 34 - Jumper Installation: 2000 Switch in Slot 5 57
Figure 35 - Jumper Installation: 2000 Switch in Slots 2 and 5 57
Figure 36 - Unit Dimensions 58
Figure 37 - 7100M Chassis Dimensions 58
Figure 38 - 7225HT Transmitter Pinout 60
Figure 39 - 7225HR Receiver Pinout 62
Figure 40 - 7100M Pin Numbers 65
Figure 41 - Mounting the Chassis and Adaptor - Detail 66
Figure 42 - Mounting the Pins and Adaptor 67
Figure 43 - Mounting the Screws (1) 67
Figure 44 - Mounting the Screws (2) 68
Figure 45 - Mounted 2300 68
Figure 46 - 2300 Dimensions 68
Figure 47 - 2300 Front Label 69
Figure 48 - 2300 Pin Numbers 71
Figure 49 - Fuse Drawer 72
Figure 50 - Voltage Selector (230 Side) 72
Figure 51 - Voltage Selector (115 Side) 72
Figure 52 - Standard 7180M and 7180M with 2380 Relay Adaptor Pinout 74
Figure 53 - 7180M with 2000 Switch Pinout 75
Figure 54 - Pinout of 7180M Jumper with 2000 Switch in Slot 2 and 5 76
Figure 55 - Pinout of 7180M Jumper with 2000 Switch in Slot 2 76
Figure 56 - Pinout of 7180M Jumper with 2000 Switch in Slot 5 77
Figure 57 - Pinout of 7180M Jumper with Tx or Rx only 77

List of Tables

Table 1 - 7225HT Transmitter LEDs 14
Table 2 - 7225HR Receiver LEDs 14
Table 3 - 7225HT Transmitter Pinout 28
Table 4 - 7225HR Receiver Pinout 30
Table 5 - 7180M Alarm Connector (J12) Pinouts 33
Table 6 - 7180M Monitor Connector (J13) Pinout 34
Table 7 - 7180M LNB Connector (J11) Pinout 35
Table 8 - Troubleshooting 37
Table 9 - 2380 Alarms Pinouts (J2) 46
Table 10 - 2380 Monitor Connector Pinout (J4) 47
Table 11 - 7225HT Transmitter Pinout 59
Table 12 - 7225HR Receiver Pinout 61
Table 13 - 7100M Alarm Connector (J9) Pinouts 63
Table 14 - 7100M Monitor Connector (J10) Pinout 64
Table 15 - 7100M LNB Connector (J11) Pinout 65
Table 16 - 2300 Alarms Pinouts (J2) 70
Table 17 - 2300 Monitor Connector Pinout (J4) 71
Table 18 - AC Voltage Fuse Part Numbers 73
Table 19 - DC Voltage Fuse Part Number 73

1. Front Chapter

1.1. Warranty and Repair Policy

Foxcom performs testing and inspection to verify the quality and reliability of our products. Foxcom uses every reasonable precaution to ensure that each unit meets specifications before shipment. Customers are asked to advise their incoming inspection, assembly, and test personnel as to the precautions required in handling and testing our products. Many of these precautions are to be found in this manual.

Nullification of Warranty

The Warranty is null and void if the product casing is opened.

The products are covered by the following warranties:

A) General Warranty

Foxcom warrants to the original purchaser all standard products sold by Foxcom to be free of defects in material and workmanship for one (1) year from date of shipment from Foxcom. During the warranty period, Foxcom will repair or replace any product that Foxcom proves to be defective. This warranty does not apply to any product which has been subject to alteration, abuse, improper installation or application, accident, electrical or environmental over-stress, negligence in use, storage, transportation or handling.

B) Specific Product Warranty Instructions

All Foxcom products are warranted against defects in workmanship, materials and construction, and to no further extent. Any claim for repair or replacement of units found to be defective on incoming inspection by a customer must be made within 30 days of receipt of shipment, or within 30 days of discovery of a defect within the warranty period.

This warranty is the only warranty made by Foxcom and is in lieu of all other warranties, expressed or implied. Foxcom sales agents or representatives are not authorized to make commitments on warranty returns.

C) Returns

In the event that it is necessary to return any product against above warranty, the following procedure shall be followed:

a. Return authorization is to be received from Foxcom prior to returning any unit. Advise Foxcom of the model, serial number, and discrepancy. The unit may then be forwarded to Foxcom, transportation prepaid. Devices returned collect or without authorization may not be accepted.

b. Prior to repair, Foxcom will advise the customer of our test results and any charges for repairing customer-caused problems or out-of-warranty conditions etc.

c. Repaired products are warranted for the balance of the original warranty period, or at least 90 days from date of shipment.

D) Limitations of Liabilities

Foxcom's liability on any claim, of any kind, including negligence for any loss or damage arising from, connected with, or resulting from the purchase order, contract, quotation, or from the performance or breach thereof, or from the design, manufacture, sale, delivery, installation, inspection, operation or use of any equipment covered by or furnished under this contact, shall in no case exceed the purchase price of the device which gives rise to the claim.

EXCEPT AS EXPRESSLY PROVIDED HEREIN, FOXCOM MAKES NO WARRANTY, EXPRESSED OR IMPLIED, WITH RESPECT TO ANY GOODS, PARTS AND SERVICES PROVIDED IN CONNECTION WITH THIS AGREEMENT INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. FOXCOM SHALL NOT BE LIABLE FOR ANY OTHER DAMAGE INCLUDING, BUT NOT LIMITED TO, INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH FURNISHING OF GOODS, PARTS AND SERVICE HEREUNDER, OR THE PERFORMANCE, USE OF, OR INABILITY TO USE THE GOODS, PARTS AND SERVICE.

The Company's exclusive warranty and the remedy provided for breach thereof shall not apply to (a) any Product used or operated other than pursuant to the Company's written instructions, (b) damage or deficiencies resulting from accident, alteration, modification, misuse, tampering, negligence, improper maintenance, installation or abuse, (c) use of any Product other than at the Installation Site, (d) use of any Product that is defective or damaged due to misuse, accident, or neglect, or due to external electrical stress, lightning or other acts of nature, (e) use of any Product by a person who is not any authorized employee of the Customer, or (f) used other than as explicitly authorized in writing by the Company.

1.2. Reporting Defects

The units were inspected before shipment and found to be free of mechanical and electrical defects.
Examine the units for any damage which may have been caused in transit. If damage is discovered, file a claim with the freight carrier immediately. Notify Foxcom as soon as possible.
Refer to Warranty and Repair Policy for further details.

Note

Keep all packing material until you have completed the inspection.

1.3. Certification

The 7225H IFL has CE, FCC, FDA, and UL certification.

1.4. Conventions

In this manual the following special formats are used:

Note

Notes contain information detailing the current topic.

CAUTION

Cautions contain information regarding situations or materials which could damage your product.

WARNING

WARNINGS CONTAIN INFORMATION REGARDING DANGEROUS FUNCTIONS.

1.5. Precautions

1.5.1. Personal Safety

WARNING

OPTICAL RADIATION

APPLYING POWER TO THE TRANSMITTER UNIT WILL CREATE A LASER ENERGY SOURCE OPERATING IN CLASS I AS DEFINED BY IEC 825-1. USE AN INFRARED VIEWER, OPTICAL POWER METER OR FLUORESCENT SCREEN FOR OPTICAL OUTPUT VERIFICATION.

AC POWER HAZARD

THE RACKMOUNT POWER SUPPLY LINE IS EMI FILTERED. THE CHASSIS IS CONNECTED TO EARTH GROUND IN COMPLIANCE WITH SAFETY REQUIREMENTS. ALWAYS USE THE 3 PRONG AC PLUG WITH EARTH GROUND TO AVOID POSSIBILITY OF ELECTRICAL SHOCK HAZARD TO PERSONNEL.

1.5.2. Equipment Safety

To avoid damaging your product, please observe the following:

1. Fuses: The 7180M does not have fuses. If the unit fails, pull the power supply out from the chassis and then push it back in.

2. The input of the transmitter has an optional built-in bias for inserting DC power up the coax to the LNB. Make certain any equipment or test equipment connected to the transmitter input can withstand this bias.

3. The output of the receiver is AC coupled and can withstand the bias from a satellite receiver. ***Do not exceed 25V DC bias.***

4. Do not allow any dirt or foreign material to get into the optical connector bulkheads. This may cause damage to the polished optical connector end faces.

5. The optical fiber jumper cable bend radius is 3 cm. Smaller radii can cause excessive optical loss and/or fiber breakage.

6. If multiple transmitters are installed in the chassis allow sufficient room for adequate ventilation; otherwise the units may overheat causing possible safety hazard or equipment damage.

7. When several units are installed on one 7180M chassis, ensure that the total current consumption (including any LNB bias) does not exceed 6A per chassis.

2. Introduction to the 7225H Interfacility Link (IFL)

The Sat-Light™ 7225H IFL transmits an L-Band RF signal over singlemode fiber from a satellite antenna LNB to control room equipment up to 5 kilometers away. The 7225H IFL is a DFB high dynamic range link for applications that require either a higher quality link or transmission over long distances. The 7225H IFL consists of an optical transmitter (7225HT) which receives the L-Band signal from the LNB and an optical receiver (7225HR) which connects to a satellite receiver.

The 7225HT and 7225HR modules plug into the 7180M[1], a 3U chassis/power supply, which enables expansion of the system to accommodate any eight Sat-Light modules. Accessories include the Model 7001P Power Supply, the Model 2000 1:1 Redundant Switch, the Model 2100 Amplifier, the 2380 Relay Adaptor, and the Model 7050 Serial Optical Multiplexer, an asynchronous data link.

The 7225H IFL transmits all satellite modulation schemes - digital or analog. Any FM modulated RF signal is transmitted accurately. The RF signal is directly modulated and adds virtually no phase noise to the original signal. The direct modulation, along with extremely flat amplitude and group delay, guarantees low bit error rate (BER) and high signal quality, independent of distance. Featuring a Multi-Quantum Well (MQW) laser diode, the 7225H IFL operates over a wide temperature range, without needing to be cooled. Slow start optical power control protects the laser from DC transients upon turn-on.

Gain Control provides for optimization of the RF signal. LEDs, and back panel monitors and alarms allow for complete system status monitoring and for interfacing with monitor and control (M&C) systems.

2.1. Options

The 7225H IFL comes with a variety of options:

1. 1550 nm laser; a 1310 nm laser is standard.

2. LNB powering; the transmitter unit can provide 14 VDC for optional LNB powering.

3. 50 or 75 Ω Input/Output Impedance/BNC female connector; Standard impedance is 50 Ω/SMA type, female connectors.

4. Standalone unit; the 7225H IFL can be installed as a standalone unit. If the 7225H is used as a standalone, a separate power supply must be used.

[1] 7100M in older models. Refer to Appendix IV 7100M Chassis for more information.

On the side of the 7225HT and the 7225HR units is a label which lists options 1 to 3. Under each option is a square[2]. If the unit includes a particular option the square under the option should be marked.



Figure 1 - Option Label

[2] There are some options on the label which are not relevant to the 7225H IFL.

2.2. Product Drawings



Figure 2 - 7225HT Transmitter Front and Rear Panel



Figure 3 - 7225HR Receiver Front and Rear Panel

2.3. Panel Descriptions

On the Front Panel of the 7225H IFL units are two LEDs. Both LEDs should be on when the unit is in use. The following tables describe the LEDs.

Table 1 - 7225HT Transmitter LEDs

LED Name	LED Function
Laser	Indicates if the laser is functional
RF	Indicates if the RF signal is within operating limits (-25 to -5 dBm)

Table 2 - 7225HR Receiver LEDs

LED Name	LED Function
Opt.	Indicates if the optical input is above the minimal level (-3 dBm)
RF	Indicates if the RF signal is within operating limits (-25 to -5 dBm)

2.4. Block Diagrams



Figure 4 - Transmitter Block Diagram



Figure 5 - Receiver Block Diagram

3. Installation

The following section details how to install the 7225H IFL units

Setting up the 7225H IFL Transmitter and Receiver consists of the following steps:

1. Setting up the transmitter.
2. Connecting the fiberoptic cable.
3. Setting up the receiver.
4. Monitoring the input/output signals.
5. Powering the IFL.
6. Connecting the back panel jumpers.
7. Aligning the fiberoptic link.

Observe all warnings and cautions mentioned at the beginning of this manual (page 10).
If after set-up you experience problems, refer to Troubleshooting on page 37.



Figure 6 - Typical Application of a 7225H IFL

3.1. Setting up the Transmitter

1. Place the 7225HT in the 7180M Chassis. The operating base plate temperature must be between -10° C to 55° C.

2. Apply AC power to the chassis. The Power Supply and Laser LEDs should be lit.

3. Using an optical power meter, measure the optical power. Insert the meter's cable into the Transmitter's optical connector. Power levels should be between 2 - 5 mW (+3 to +7 dBm).

Alternatively, use a DVM to measure the voltage at:

- pins J13-P17 through J13-P24 for the slot being measured (Refer to Table 6 on page 34 for details regarding J13 pinouts) (7180M Rackmount)
- at pin #6 of the 9 pin connector (standalone)
- The signal level should be -4.2 to -4.8V.

4. On the rear panel, connect the coax cable to the RF Input Connector. The RF LED should be lit.

5. On the rear panel, connect the fiberoptic cable to the Optical Connector.

6. Adjust the Gain Control Potentiometer to give the desired output power. Using a small screw driver, turn the potentiometer (located on the front panel) to increase or decrease the gain.

- To ***increase*** the gain, turn the gain control clockwise.
- To ***decrease*** the gain, turn the gain control counterclockwise.
- For more information refer to Aligning the Fiberoptic Link on page 24.

Note

If either LED is not lit, refer to Troubleshooting on page 37.

CAUTION

When monitoring the voltage outputs use only a high resistance DVM.

3.2. Connecting the Fiberoptic Cable

Before connecting the cable:

1. The fiberoptic cable ***must*** be either fusion spliced or connected via FC/APC connectors.
2. Wipe the connector with a lint-free cotton cloth.
3. Note the polarity key of the optical connector before inserting.

To connect the cable:

1. Line Up the Polarity Key.



2. Insert the connector.



3. Tighten the connector.



CAUTION

Do not apply any glue, silicon adhesive, or any other material to the fiberoptic connector!

3.3. Setting Up the Receiver

1. Place the 7225R Receiver in any of the 7180M Chassis, unless a 2000 RF Switch is installed (refer to Figure 7, page 21). The operating base plate temperature must be between -10° C to 55° C.

Note

If a 2000 RF Switch(s) is being installed, then slots 2 and/or 5 of the 7180M are reserved for the switch(es).

2. Apply AC power to the chassis. The Power Supply's LED should be lit.

3. On the rear panel connect the fiberoptic cable to the Optical Connector. The Opt. LED should be lit (if the Transmitter is operating correctly).

4. Using an optical power meter, measure the optical power coming to the Receiver from the fiberoptic cable. The power levels of the Receiver should be the power level measured at the Transmitter minus the fiber loss[3].

Alternatively, use a DVM to measure the voltage at:

- pins J13-P7 through J10-P12 for the slot being measured (Refer to Table 6 on page 34 for details regarding J13 pinouts) (7180M Rackmount). The voltage level should be 1V for each 1 mW measured at the Receiver input.
- at pin #5 of the 9 pin connector (standalone)

5. On the rear panel, connect the coax cable to the RF Output Connector.

6. Adjust the Gain Control Potentiometer to give the desired output power. Using a small screw driver, turn the potentiometer (located on the front panel) to increase or decrease the gain.

Note

The potentiometer is 10 turn potentiometer.

- To ***increase*** the gain, turn the gain control clockwise.
- To ***decrease*** the gain, turn the gain control counterclockwise.
- For more information refer to Aligning the Fiberoptic Link on page 24.

Note

If either LED is not lit, refer to Troubleshooting on page 37.

[3] Fiber loss is defined as:
(attenuation/km x length (km) of the fiberoptic cable) + (1.0 dB x number of connectors).
For example if a signal with an optical wavelength of 1310 nm is transmitted over a link 10 kilometers long which had two connectors the loss would be:
(0.4 dB/km x 10 km) + (0.5 dB x 2) = 5.0 dB

Alternatively if a signal with an optical wavelength of 1550 nm is transmitted over a link 10 kilometers long which had two connectors the loss would be:
(0.27 dB/km x 10 km) + (0.5 dB x 2) = 2.7 dB

3.3.1. Measuring the RF Signal Strength

The RF signal strength can be monitored during operation via a DC RF signal-strength monitor. Maintenance personnel can perform a simple verification process.

To measure the RF signal strength:

- **Rackmount Connector:** Using a Digital Volt Meter, measure the voltage at J13P1 to P8.
- **2380/2300 Relay Adapter:** Using a Digital Volt Meter, measure the voltage at J4P1 to P8.
- **Standalone:** Using a Digital Volt Meter, measure the voltage at the connector pin #4.

The nominal level is 3 to 4 VDC.

3.4. Powering the IFL

- Transmitter power requirement: 15VDC @ 270mA (excluding LNB Drive option).
- Receiver power requirement: 15VDC @ 360mA.
- The Standalone Transmitter/Receiver is powered by a Foxcom-supplied external DC power supply.
- The Rackmount Transmitters/Receivers are plugged into the rackmount chassis. The chassis can accept and power up to eight units.

Note

At temperatures below -10°C, the Transmitter's internal heater will require an additional 120 mA. The Transmitter's total power requirement will then be 390 mA.

CAUTION

Ensure that there is a good airflow around the chassis rackmount.

3.4.1. 7180M Chassis

The 7180M Chassis provides power to the plug in units. The power supply is a switching type. Each plug-in regulates its own voltage. The power supply provides:

- 14 VDC stable
- AC input; 100 - 240 VAC
- Units can be plugged in "hot standby"



Figure 7 - 7180M Chassis Rear View

3.5. Connecting the Back Panel Jumpers

On the rear panel of the 7180M Back Panel are product selectors (JP1 to JP4). The 3 pin selectors (male) are the connecting point between the slots and the back panel. One pin is for the transmitter/receiver (Tx/Rx), one is for the optional 2000 1:1 Redundant Switch, and one is for the 7180M. A 2 pin jumper (female) is placed on the relevant pins to complete the connection between the 7180M and the units. For example, if a 2000 Switch is being used, the jumper is placed on the Switch-7180M pins.

To connect the jumpers:

1. Each jumper has two sets of pins, upper and lower. The upper pins are labeled SW (Switch) and the lower pins Tx/Rx.

2. If the 7180M has Tx or Rx units only, place all jumpers on the lower two pins.



Figure 8 - Jumper Installation: Tx and Rx Only

3. If the 2000 Switch is installed in Slot 2, place the JP1 and JP2 jumpers on the higher two pins and the JP3 and JP4 jumpers on the lower two pins.



Figure 9 - Jumper Installation: 2000 Switch in Slot 2

4. If the 2000 Switch is installed in Slot 5, place the JP1 and JP2 jumpers on the lower two pins and the JP3 and JP4 jumpers on the higher two pins.



Figure 10 - Jumper Installation: 2000 Switch in Slot 5

5. If the 2000 Switch is installed in Slots 2 and 5, place the JP1, JP2, JP3, and JP4 jumpers on the higher two pins.



Figure 11 - Jumper Installation: 2000 Switch in Slots 2 and 5

3.6. Measuring the RF Signal Strength

The Receiver's RF signal strength can be monitored during operation via a DC RF signal-strength monitor. Maintenance personnel can perform a simple verification process.

To measure the RF signal strength:

1. Using a Digital Volt Meter, measure the voltage at the connector pin #4 (both Rackmount and Standalone).

3.7. Aligning the Fiberoptic Link

The final step in installing the System 7225H is re-adjusting the Receiver Gain Control for unity gain.

To set the unity gain (standard version)[4]:

1. Connect combiner output to input of Spectrum Analyzer (S.A.).
2. Set Signal Generator 1 to -8 dBm on the S.A. at 1500 MHz.
3. Repeat for S.G.2, at 1510 MHz.
4. Set up the system as shown in Figure 12.
5. Set the Transmitter Gain Control for 3rd order intermodulation level of -50 dBc at the Receiver output.
6. Adjust the Receiver Gain Control for unity gain.



Figure 12 - Fiberoptic Alignment Setup

[4] If you are unable to perform this procedure refer to Gain Control, page 36 .

4. Product Specifications

The following section details the:

- 7225H IFL specifications
- Model dimensions
- 7225H Pinouts
- 7180M Pinouts

4.1. 7225H IFL Specifications

RF Specifications	
Frequency Range	950 - 2150 MHz (2500 MHz optional)
Flatness 950 - 2150 MHz	± 1.0 dB (typical)
Flatness 950 - 2500 MHz[5]	± 2.5 dB (max.)
Flatness @ 36 MHz	± 0.2 (max.)
Input/Output Impedance	50 Ω SMA (75 Ω option)
Return Loss	1.5:1 @ 50 Ω Impedance (max.) 1.57:1 dB @ 75 Ω Impedance (max.)
Intermodulation Products[6]	-50 dBc (max.)
Noise Figure[7]	25 dB
Output IP_3[8]	+15 dBm
Input Signal Range (Total Power)	-25 to -5 dBm
Output Signal Range (Total Power)	-25 to -5 dBm
CNR @ 36 MHz / 2 Kilometers	60 dB
Gain Control	Manual
Link Gain[9]	0 ± 10 dB (within total power range)
SFDR[10]	109 dB Hz 2/3 @ -25 dBm (typ)
Maximum Input Power[11]	+ 10 dBm
RF Connector	SMA (BNC optional)

[5] Flatness between 950 – 2150 MHz is ±1.5 dB. In the bandwidth between 2150 – 2500 MHz the flatness rises to ± 2.5 dB.

[6] At nominal conditions

[7] @ Maximum Input @ 1 dB Optical Loss @ Unity Gain

[8] This specification is true when: IMD = -40 dBc, Pout = -5 dBm

[9] Full gain range is obtainable when in the input/output signal power is within specified range

[10] @ Maximum Input

[11] With no damage

Optical Specifications	
Optical Wavelength	1310 ± 10 nm (1550 nm optional)
Optical Power Output	+3 to +7 dBm/2 to 5 mW
Optical Connector	FC/APC
Optical Budget	5 kilometers @ 3 dB
Optical Return Loss	-60 dB
Physical Specifications	
Power for Standalone **Transmitter** **Receiver**	 +15 VDC @ 330 mA (450 mA @ temp. -10° C) +15 VDC @ 360 mA
Power for Rackmount (max.)	100 to 240 VAC 50/60Hz 90 Watts
Chassis Size	19” x 3U x 7”
Chassis Capacity	6 plug-ins, and 2 power supplies
Standalone Size	4” x 4.8” x 1.3”
Optical Connector	FC/APC
Operating Temperature Range	-10° C to +55° C
Storage Temperature Range	-40° C to +85° C

All specs are subject to change without prior notice.

Note

Optical fiber plant must be singlemode 9/125 and low reflection. ***Use FC/APC connectors only.***

4.2. Model Dimensions



Figure 13 - Unit Dimensions



Figure 14 - 7180M Chassis Dimension

4.3. 7225H IFL Pinouts

Table 3 - 7225HT Transmitter Pinout

Standalone 9 Pin Connector (J13)	7180M Chassis Back Panel Connector	2300 Relay Adaptor Connector	Name	Description
1	—	—	+15V Power	330 mA (excluding LNB drive)
2	—	—	Spare	Not Used
3	J11-P9 J12-P25 J13-P25	J2-P25 J4-P25	GND	Chassis Ground
4	J13-P1 to J13-P8	J4-P1 to J4-P8	RSSI	RF Signal Strength Indicator; Range 3 - 4 VDC
5	J13-P9 to J13-P16	J4-P9 to J4-P16	PDI	Indicates Laser Optical Power; Range -1.5 to -4.5V
6	J13-P17 to J13-P24	J4-P17 to J4-P24	LSRI	Indicates Laser Bias; Range -4.2 to -4.8V
7	J12-P1 to J12-P8	J2: P1-P2 P3-P4, P5-P6 P7-P8, P9-P10 P11-P12 P13-P14 P15-P16	RFA	RF Alarm: Open collector interface.[12] Sinks current when RF level is low, up to 30 mA
8	J12-P9 to J12-P16	**See Note Below**	OPTA	Optical Alarm: Open collector interface[13]. Sinks current when optical level is low, up to 30 mA.
9	J11-P1 to J11-P6		LNB Bias (optional)*	External LNB Bias

***Dependent on order**

Note

If a 2380 Relay Adaptor is installed RF and Optical Levels are measured together; the alarm indicates a problem in either the RF or Optical Levels.

[12] If the 2380 Relay Adapter is installed, the alarms are dry contact. Refer to Appendix III The 2380 Relay Adaptor.

[13] ibid



Figure 15 - 7225HT Transmitter Pinout

Table 4 - 7225HR Receiver Pinout

Standalone 9 Pin Connector (J14)	7180M Chassis Back Panel Connector	2380 Relay Adaptor Connector	Name	Description
1	—	—	+15V Power	360 mA
2	—	—	Spare	Not Used
3	J11-P9 J12-P25 J13-P25	J2-P25 J4-P25	GND	Chassis Ground
4	J13-P1 to J13-P8	J4-P1 to J4-P8	RSSI	RF Signal Strength Indicator; Range 0.2 - 10.5V
5	J13-P9 to J13-P16	J4-P9 to J4-P16	PDI	Indicates Received Optical Power; 1V/1mW Optical Power
6	—	—	Spare	Not Used
7	J12-P1to J12-P8	J2: P1-P2 P3-P4, P5-P6 P7-P8, P9-P10 P11-P12 P13-P14 P15-P16	RFA	RF Alarm: Open collector interface[14]. Sinks current when RF level is low, up to 30 mA.
8	J12-P9 to J12-P16	**See Note Below**	OPTA	Optical Alarm: Open collector interface[15]. Sinks current when optical level is low, up to 30 mA.
9	—	—	Spare	Not Used

Note

If a 2380 Relay Adaptor is installed RF and Optical Levels are measured together; the alarm indicates a problem in either the RF or Optical Levels.

[14] If the 2380 Relay Adapter is installed, the alarms are dry contact. Refer to to Appendix III The 2380 Relay Adaptor.

[15] If the 2380 Relay Adapter is installed, the alarms are dry contact. Refer to section to Appendix III The 2380 Relay Adaptor.



Figure 16 - 7225HR Receiver Pinout

4.4. 7180M Chassis Pinouts[16]

The unit's pins are found at the backplane of the 7180M chassis. The 7180M chassis backplane incorporates 8 slots. Pinouts from the nine pin connector at each slot are sent through the backplane assembly to the two 25 pin D connectors, J12 and J13, and one nine pin connector, J11. Any monitor voltages to be measured may be done between the chassis ground and the required pin.



Figure 17 - 7180M Chassis Rear View

[16] Refer to Appendix V Pinouts, Detailed Information for further information.

The pins are numbered as follows:

Table 5 - 7180M Alarm Connector (J12) Pinouts

Pin No.	Function	Name	Slot No.
1	RF Alarm	RFA1	1
2	RF Alarm	RFA2	2
3	RF Alarm	RFA3	3
4	RF Alarm	RFA4	4
5	RF Alarm	RFA5	5
6	RF Alarm	RFA6	6
7	RF Alarm	RFA7	7
8	RF Alarm	RFA8	8
9	Optical Alarm	OptAlm1	1
10	Optical Alarm	OptAlm2	2
11	Optical Alarm	OptAlm3	3
12	Optical Alarm	OptAlm4	4
13	Optical Alarm	OptAlm5	5
14	Optical Alarm	OptAlm6	6
15	Optical Alarm	OptAlm7	7
16	Optical Alarm	OptAlm8	8
17			
18			
19			
20			
21	Standby Power Supply	SPSNOP	
22	Standby Power Supply	SPSCOM	
23	Main Power Supply	MPSNOP	
24	Main Power Supply	MPSCOM	
25	Chassis Ground	GND	

Table 6 - 7180M Monitor Connector (J13) Pinout

Pin No.	Function	Name	Slot No.
1	RSSI Monitor	RSSI1	1
2	RSSI Monitor	RSSI2	2
3	RSSI Monitor	RSSI3	3
4	RSSI Monitor	RSSI4	4
5	RSSI Monitor	RSSI5	5
6	RSSI Monitor	RSSI6	6
7	RSSI Monitor	RSSI7	7
8	RSSI Monitor	RSSI8	8
9	PDI Monitor	PDI1	1
10	PDI Monitor	PDI2	2
11	PDI Monitor	PDI3	3
12	PDI Monitor	PDI4	4
13	PDI Monitor	PDI5	5
14	PDI Monitor	PDI6	6
15	PDI Monitor	PDI7	7
16	PDI Monitor	PDI8	8
17	LSRI Monitor	LSRI1	1
18	LSRI Monitor	LSRI2	2
19	LSRI Monitor	LSRI3	3
20	LSRI Monitor	LSRI4	4
21	LSRI Monitor	LSRI5	5
22	LSRI Monitor	LSRI6	6
23	LSRI Monitor	LSRI7	7
24	LSRI Monitor	LSRI8	8
25	Chassis Ground	GND	

Table 7 - 7180M LNB Connector (J11) Pinout

Pin No.	Function	Name	Slot No.
1	LNB Powering	LNB1	1
2	LNB Powering	LNB2	2
3	LNB Powering	LNB3	3
4	LNB Powering	LNB4	4
5	LNB Powering	LNB5	5
6	LNB Powering	LNB6	6
7	LNB Powering	LNB7	7
8	LNB Powering	LNB8	8
9	GND	GND	



Figure 18 - 7180M Pin Numbers

4.4.1. 7180M and Redundancy Switching

The 2000 Switch provides optional 1:1 redundancy switching for all Foxcom Interfacility Links. If the customer chooses to add redundancy switching to the link, the pin connector jumpers need to be moved. Detailed instructions on moving the jumpers are provided in the *Model 2000 1:1 Redundant Switch Installation and User's Guide (Document Number 93-010-01).*

5. Gain Control

The 7225H IFL unit requires no maintenance, but the user can adjust the transmitter and receiver gain by 20 dB. The gain can be between 0 to -20 dB.

All internal adjustments have been set up at the factory; the only user adjustments are input and output RF signal levels accessible from the front panel and described in the following sections. A detailed procedure for optimizing the gain control is provided in Section 3.7 Aligning the Fiberoptic Link.

If you do not have a signal generator or spectrum analyzer, adjust the gain according to the following procedure.

To adjust the Transmitter Gain:

1. Set the input power to the expected power level.
2. Set the nominal RSSI signal at 3.5 V ± 0.5.

To adjust the Receiver Gain:

1. Set the input power to the expected power level.
2. Set the nominal RSSI signal at 5.0 V ± 2.

6. Troubleshooting

The 7225H IFL was tested before it left the factory. However if you are experiencing difficulties consult the list below for possible solutions. If your system is still experiencing problems, please attempt to isolate and identify the malfunctioning unit.

Table 8 - Troubleshooting

PROBLEM	POSSIBLE CAUSE
1. Laser LED not on	1. No DC power to the unit. Possible power supply problem or AC power input problem. Check the power supply fuse. 2. Verify LSRI monitor is between -4.8 and -4.2V. If not, laser may have overheated. Disconnect power or remove plug in and allow cooling. Try again with better airflow. 3. If an optical power meter is available, measure the optical power out of the transmitter. The power should be 2 to 5 mW (+3 to +7 dBm). If an optical power meter is not available, then use another receiver to determine if there is optical power emerging from the transmitter (use the 5 meter jumper cable). If there is no optical power, then the transmitter unit is malfunctioning. If any or all the above are not within the guidelines, the transmitter unit is faulty.
2. Lack of RF signal present at Receiver, yet optical power is functioning.	1. If the unit has an LNB drive option, verify that the correct LNB bias is coming down the center of the RF connector at the transmit site. 2. Verify that the dish is pointed and correctly receiving satellite signals. Conclusion: If signal still not present then Transmitter input stage amplifier is defective. Contact Foxcom.
3. No optical power, LED not illuminated.	1. There is a break or severe bend in the fiberoptic cable. Use an optical power meter or another functioning receiver unit to verify optical power coming down the fiber. 2. Optical power too low, too many splits, too long a distance (thus exceeding optical budget). System *may still function* without LED illuminated although at reduced performance. 3. The transmitter is not functioning, see above.

PROBLEM	**POSSIBLE CAUSE**
4. Optical power light illuminated with disconnected optical input.	Damaged (leaky) photodiode. Unit may still function, otherwise contact Factory for service.

7. Appendix 1 Cleaning Fiberoptic Connections

The unit has an FC/APC angle polished optical connector for very high optical return loss performance. The units are specified into singlemode fiber i.e. 9/125 micron core diameter. Full performance is specified only for low return loss optical plant - meaning that the fiber must be fusion spliced and all connections or splices must have a return loss greater than -60 dB. With these guidelines in mind, link lengths beyond 20 kilometers (DFB based products) can be achieved with high performance. Specific performance and/or design assistance is available by request from Foxcom.

If there is low/no signal or noisy signal at a Foxcom module, the connector should be cleaned. Dirt on the inside connector tip can impair the flow of light causing problems in signal transmission. Foxcom modules are sealed but dirt can occasionally enter during installation and alignment.

The input and output optical ports of all Foxcom equipment are known in the fiber optic world as bulkhead ports. Foxcom uses FC/APC connectors.

The purpose of this document is to define the cleaning procedure for the FC/APC bulkhead fiberoptic ports and for the fiberoptic connector which is connected to the bulkhead port.

The following materials are representative of the types of cleaning materials that should be used for cleaning the fiberoptic ports and connectors. They are available from several suppliers.

Description	**Manufacturer**
Kimwipes	Kimberly Clark
Cletop Automatic Connector Cleaner	Cletop
Fiberoptic Swab	Cletop or FIS
Fiberoptic Compressed Air	Chemtronics

Wiping clothes should be made of lint free alcohol free nonabrasive materials. Swabs should have a tightly wrapped tip and be talcum free. For removing dust from receptacles, a canned compressed gas is recommended. Do not use commercial compressed air because of risk of contamination.

7.1. Cleaning Procedures for FC/APC Connectors

Use a Kim Wipe to gently wipe the end face surface of the connector. Alternatively a Cletop automatic connector cleaner can be used.

Figure 19 - Wiping the Connector with a Kim Wipe



Figure 20 - Wiping the Connector with a Kim Wipe (2)

7.2. Cleaning Procedure for FC/APC Bulkhead Ports

CAUTION

Clean the transmitter and receiver optical ports only when there is evidence of contamination or reduced performance.

7.2.1. Swab Method

Using a clean fiber optic cleaning swab, gently wipe out the optical port. Discard the swab after use.



Figure 21 - Cleaning the Optical Port



Figure 22 - Cleaning the Optical Port (2)

7.2.2. Compressed Air Method

Using the extension tube of the compressed air, blow into the port to remove any dust or debris. Do not allow the tube to touch the bottom of the port. Do not use commercial compressed air due to potential oil contamination.

Note

To prevent contamination, the optical ports should be connected or covered with a dust cap at all times.

Use dry air or nitrogen only.

8. Appendix II Installing a Standalone Unit

To install the 7225HT-STD or 7225HR-STD Standalone:

1. Place the 7225H unit on the standalone flange, matching the holes.
2. Using four screws (#4 or #6) secure the unit and the flange to the wall.
3. Apply AC power to the standalone power supply unit.
4. Connect the 7225H unit to the power supply. The Laser LED should be lit.

All remaining steps are the same as in the product manual. Refer to Installation on page 18.

9. Appendix III The 2380 Relay Adaptor

The following section describes how to install the 2380 Relay Adaptor onto the 7180M Chassis. The 2380 Relay Adaptor assembly provides dry contact output signals as an option to the standard open collector signals available on the 7180M chassis backplane.

If the 2380 Relay Adaptor is ordered separately from the 7180M chassis, it must be mounted by the user. The 2380 is easily mounted directly over the connectors on the 7180M backplane, as shown below.

9.1. Installing the 2380 - Parts Needed

- 2380 Relay Adapter
- Two pin guides
- Four one inch screws
- Screw driver

9.2. Installing the 2380 - Procedure

To mount to the 2380 Relay Adapter:

WARNING

DO NOT PERFORM THIS PROCEDURE BEFORE DISCONNECTING THE ELECTRICITY

1. Disconnect the electricity.
2. Make sure that you have all the needed equipment.
3. Install the pin guides.



Figure 23 - Mounting the Chassis and Adaptor - Detail

4. Mount the unit onto the pin guides.



Figure 24 - Mounting the Pins and Adaptor

5. Mount the four screws. The screws must be installed in the order shown in Figure 25 and Figure 26.



Figure 25 - Mounting the Screws (1)



Figure 26 - Mounting the Screws (2)

CAUTION

Use only the mounting screws provided by Foxcom. Using other screws can permanently damage the unit!



Figure 27 - Mounted 2380

6. Connect the cables.

9.3. 2380 Dimensions and Front Panel Label



Figure 28 - 2380 Dimensions



Figure 29 - 2380 Front Label

9.4. 2380 Pinouts

The following table details the 2380 Alarms pinouts.

Table 9 - 2380 Alarms Pinouts (J2)

Pin Number	Function[17]	Name	Slot Number
1	Alarm	NOP1	1
2	Alarm	COM1	1
3	Alarm	NOP2	2
4	Alarm	COM2	2
5	Alarm	NOP3	3
6	Alarm	COM3	3
7	Alarm	NOP4	4
8	Alarm	COM4	4
9	Alarm	NOP5	5
10	Alarm	COM5	5
11	Alarm	NOP6	6
12	Alarm	COM6	6
13	Alarm	NOP7	7
14	Alarm	COM7	7
15	Alarm	NOP8	8
16	Alarm	COM8	8
17			
18			
19			
20			
21			
22			
23	Main PS Alarm	MPSA	
24	Standby PS Alarm	SPSA	
25	Power Supply Comm.	PSCOM	

[17] Alarms in Pins 1 through 16 function if there is either a RF or Optical signals failure.

Table 10 - 2380 Monitor Connector Pinout (J4)

Pin No.	Function	Name	Slot No.
1	RSSI Monitor	RSSI	1
2	RSSI Monitor	RSSI	2
3	RSSI Monitor	RSSI	3
4	RSSI Monitor	RSSI	4
5	RSSI Monitor	RSSI	5
6	RSSI Monitor	RSSI	6
7	RSSI Monitor	RSSI	7
8	RSSI Monitor	RSSI	8
9	PDI Monitor	PDI1	1
10	PDI Monitor	PDI2	2
11	PDI Monitor	PDI3	3
12	PDI Monitor	PDI4	4
13	PDI Monitor	PDI5	5
14	PDI Monitor	PDI6	6
15	PDI Monitor	PDI7	7
16	PDI Monitor	PDI8	8
17	LSRI Monitor	LSRI1	1
18	LSRI Monitor	LSRI2	2
19	LSRI Monitor	LSRI3	3
20	LSRI Monitor	LSRI4	4
21	LSRI Monitor	LSRI5	5
22	LSRI Monitor	LSRI6	6
23	LSRI Monitor	LSRI7	7
24	LSRI Monitor	LSRI8	8
25	Chassis Ground	GND	



Figure 30 - 2380 Pin Numbers

10. Appendix IV 7100M Chassis

The 7100M Chassis is a standard Foxcom Chassis which holds up to 6 units.

If a 7225H IFL is being installed into a 7100M the following information should be used for installing and checking the unit.

10.1. Equipment Safety

To avoid damaging your product, please observe the following:

1. Fuses: To avoid possibility of fire hazard, always replace fuses with the same type and rating of fuse as recommended on the power supply rear label.
In the US/Canada 1A fuses must be used (**refer to page 73**).
In Europe/Asia/South America 0.5A fuses must be used.

2. The input of the transmitter has an optional built-in bias for inserting DC power up the coax to the LNB. Make certain any equipment or test equipment connected to the transmitter input can withstand this bias.

3. The transmitter and receiver output are DC coupled and can withstand the bias from a satellite receiver. ***Do not exceed 25V DC bias.***

4. Do not allow any dirt or foreign material to get into the optical connector bulkheads. This may cause damage to the polished optical connector end faces.

5. The optical fiber jumper cable bend radius is 3 cm. Smaller radii can cause excessive optical loss and/or fiber breakage.

6. If multiple transmitters are installed in the chassis allow sufficient room for adequate ventilation; otherwise the units may overheat causing possible safety hazard or equipment damage.

7. When several units are installed on one 7100M chassis, ensure that the total units' current (including any LNB bias) does not exceed 2A per power supply.

CAUTION

If several units in one chassis use the LNB option, the total current may exceed 2A. Over current in this configuration and a failure of one power supply may blow the fuse in the spare power supply.

10.2. Installation

The following section details the steps in the installation process which differ from units installed in the 7180M Chassis. All other steps are the same.

CAUTION

By default, a 7225H IFL installed in a 7100M is set to 230V. To change the voltage to 115V, refer to page 72, Changing the Primary Power Setting.

Observe all warnings and cautions mentioned at the beginning of this manual (page 10. If after set-up you experience problems, refer to Troubleshooting, page 37.

10.2.1. Setting up the Transmitter

1. Place the 7225HT in the 7100M Chassis. The operating base plate temperature must be between -10° C to 55° C.

2. Apply AC power to the chassis. The Power Supply's LED should be lit.

3. Mount the 7225HT into the chassis. The Laser LED should be lit.

4. Using an optical power meter, measure the optical power. Insert the meter's cable into the Transmitter's optical connector. Power levels should be between 2 - 5 mW (+3 to +7 dBm).

Alternatively, use a DVM to measure the voltage at:

- pins J10-P13 through J10-P18 for the slot being measured (Refer to Table 14 on page 64 for details regarding J10 pinouts) (7100M Rackmount)
- at pin #6 of the 9 pin connector (standalone)

The voltage level should be -4.2 to -4.8V.

5. On the rear panel, connect the coax cable to the RF Input Connector.

6. On the rear panel, connect the fiberoptic cable to the Optical Connector.

7. Adjust the Gain Control Potentiometer to give the desired output power. Using a small screw driver, turn the potentiometer (located on the front panel) to increase or decrease the gain.

- To ***increase*** the gain, turn the gain control clockwise.
- To ***decrease*** the gain, turn the gain control counterclockwise.
- For more information refer to Aligning the Fiberoptic on page 24.

Note

If either LED is not lit, refer to Troubleshooting on page 37.

CAUTION

When monitoring the voltage outputs use only a high resistance DVM.

10.2.2. Connecting the Fiberoptic Cable

Before connecting the cable:

1. Wipe the connector with a lint-free cotton cloth.
2. Note the polarity key of the optical connector before inserting.

To connect the cable:

1. Line Up the Polarity Key.



2. Insert the connector.



3. Tighten the connector.



10.2.3. Setting Up the Receiver

1. Place the 7225H Receiver in the 7100M Chassis. The operating base plate temperature must be between -10° C to 55° C.

2. Apply AC power to the chassis. The Power Supply's LED should be lit.

3. Mount the 7225HR into the chassis.

4. On the rear panel connect the fiberoptic cable to the Optical Connector. The Opt. LED should be lit (if the Transmitter is operating correctly).

5. Using an optical power meter, measure the optical power coming to the Receiver from the fiberoptic cable. The power levels of the Receiver should be the power level measured at the Transmitter minus the fiber loss[18].

Alternatively, use a DVM to measure the voltage at:

- pins J10-P7 through J10-P12 for the slot being measured (Refer to Table 14, page 64 for details regarding J10 pinouts) (7100M Rackmount). The voltage level should be 1V for each 1 mW measured at the Receiver input.
- at pin #5 of the 9 pin connector (standalone)

6. On the rear panel, connect the coax cable to the RF Output Connector.

7. Adjust the Gain Control Potentiometer to give the desired output power. Using a small screw driver, turn the potentiometer (located on the front panel) to increase or decrease the gain.

- To ***increase*** the gain, turn the gain control clockwise.
- To ***decrease*** the gain, turn the gain control counterclockwise.
- For more information refer to Aligning the Fiberoptic on page 24.

Note

If either LED is not lit, refer to Troubleshooting on page 37.

[18] Fiber loss is defined as:
(attenuation/km x length (km) of the fiberoptic cable) + (1.0 dB x number of connectors).
For example if a signal with an optical wavelength of 1310 nm is transmitted over a link 10 kilometers long which had two connectors the loss would be:
(0.4 dB/km x 10 km) + (0.5 dB x 2) = 5.0 dB

Alternatively if a signal with an optical wavelength of 1550 nm is transmitted over a link 10 kilometers long which had two connectors the loss would be:
(0.27 dB/km x 10 km) + (0.5 dB x 2) = 2.7 dB

10.2.4. Measuring the RF Signal Strength

The Receiver's RF signal strength can be monitored during operation via a DC RF signal-strength monitor. Maintenance personnel can perform a simple verification process.

To measure the RF signal strength:

1. Using a Digital Volt Meter, measure the voltage at the connector pin #4 (both Rackmount and Standalone).

10.2.5. Powering the IFL

- Transmitter power requirement: 15VDC @ 270mA (excluding LNB Drive option).
- Receiver power requirement: 15VDC @ 360mA.
- The Standalone Transmitter/Receiver is powered by a user-supplied external DC power supply.
- The Rackmount Transmitters/Receivers are plugged into the rackmount chassis. The chassis can accept and power up to six units.

Note

At temperatures below -10 °C, the Transmitter's internal heater will require an additional 120 mA. The Transmitter's total power requirement will then be 390 mA.

CAUTION

Ensure that there is a good airflow around the chassis rackmount.

Note

By default the power supply is set to 220V (0.5A).

7100M Chassis

The 7100M Chassis provides power to the plug in units. The power supply is a linear unregulated type. Each plug-in regulates its own voltage. The power supply provides:

- 15 to 18 VDC (unregulated) @ 2.2 amps power
- AC input @ 110/220 VAC (user selected)
- Units can be plugged in "hot standby"
- An internal 5 amp fuse (refer to Changing the Primary Power Setting page 72 for the fuse part numbers)

Note

By default the power supply is set to 220V (0.5A).



Figure 31 - 7100M Chassis Rear View

10.2.6. Connecting the Back Panel Jumpers

On the rear panel of the 7100M Back Panel are product connectors (JP1 to JP4). The 3 pin connectors (male) are the connecting point between the slots and the back panel. One pin is for the Tx/Rx, one is for the 2000 RF Switch, and one is for the 7100M. A 2 pin jumper (female) is placed on the relevant pins to complete the connection between the 7100M and the units. For example, if a 2000 RF Switch is being used, the jumper is placed on the Switch-7100M pins.

To connect the jumpers:

1. Each jumper has two sets of pins, upper and lower. The upper pins are labeled SW (Switch) and the lower pins Tx/Rx (Transmitter/Receiver).

2. If the 7100M has Tx or Rx units only, place all jumpers on the lower two pins.



Figure 32 - Jumper Installation: Tx and Rx Only

3. If the 2000 Switch is installed in Slot 2, place the JP1 and JP2 jumpers on the higher two pins and the JP3 and JP4 jumpers on the lower two pins.



Figure 33 - Jumper Installation: 2000 Switch in Slot 2

4. If the 2000 Switch is installed in Slot 5, place the JP1 and JP2 jumpers on the lower two pins and the JP3 and JP4 jumpers on the higher two pins.



Figure 34 - Jumper Installation: 2000 Switch in Slot 5

5. If the 2000 Switch is installed in Slots 2 and 5, place the JP1, JP2, JP3, and JP4 jumpers on the higher two pins.



Figure 35 - Jumper Installation: 2000 Switch in Slots 2 and 5

10.3. Model Dimensions



Figure 36 - Unit Dimensions



Figure 37 - 7100M Chassis Dimensions

10.4. 7225H IFL Pinouts (7100M Chassis)

Table 11 - 7225HT Transmitter Pinout

Standalone 9 Pin Connector (J14)	7100M Chassis Back Panel Connector	2300 Relay Adaptor Connector	Name	Description
1	—	—	+15V Power	330 mA (excluding LNB Drive)
2	—	—	Spare	Not Used
3	J9-P25 J10-P25 J11-P9	J2-P25 J4-P25	GND	Chassis Ground
4	J10-P1 to J10-P6	J4-P1 to J4-P6	RSSI	RF Signal Strength Indicator; Range 3 to 4 VDC
5	J10-P7 to J10-P12	J4-P7 to J4-P12	PDI	Indicates Laser Optical Power; Range -2 to -4.5V
6	J10-P13 to J10-P18	J4-P13 to J4-P18	LSRI	Indicates Laser Bias; Range -4.8 to -4.2 VDC
7	J9-P1to J9-P6	J2-P2, P5, P8, P11, P14, P17	AGC Alarm	RF Alarm: Open collector interface. Sinks current at low RF, up to 30 mA
8	J9-P14 to J9-P19	J2-P1, P4, P7, P10, P13, P16	OPTA	Optical Alarm: Open collector interface. Sinks current at low optical, up to 30 mA
9	J11-P1 to J11-P6	—	LNB Bias (optional)*	External LNB Bias

***Dependent on order**



Figure 38 - 7225HT Transmitter Pinout

CAUTION

When monitoring the voltage outputs use only a high resistance DVM.

Table 12 - 7225HR Receiver Pinout

Standalone 9 Pin Connector (J14)	7100M Chassis Pin Back Panel Connector	2300 Relay Adaptor Connector	Name	Description
1	—	—	+15V Power	360mA
2	—	—	Spare	Not Used
3	J9-P25 J10-P25 J11-P25	J2-P25 J4-P25	GND	Chassis Ground
4	J10-P1 to J10-P6	J4-P1 to J4-P6	RSSI	RF Signal Strength Indicator; Range 0.2 to 10.5V
5	J10-P7 to J10-P12	J4-P7 to J4-P12	PDI	Indicates Received Optical Power; 1V/1mW Optical Power
6	—	—	Spare	Not Used
7	J9-P1 to J9-P6	J2-P2, P5, P8, P11, P14, P17	AGC Alarm	RF Alarm: Open collector interface[19]. Sinks current when RF level is low, up to 30 mA.
8	J9-P14 to J9-P19	J2-P1, P4, P7, P10, P13, P16	OPTA	Optical Alarm: Open collector interface[20]. Sinks current when optical level is low, up to 30 mA.
9	—	—	Spare	Not Used

[19] If the 2300 Relay Adapter is installed, the alarms are dry contact. .

[20] If the 2300 Relay Adapter is installed, the alarms are dry contact.



Figure 39 - 7225HR Receiver Pinout

CAUTION

When monitoring the voltage outputs use a high resistance DVM only.

10.5. 7100M Pinouts

The unit's pins are found at the backplane of the 7100M chassis. The 7100M backplane incorporates 6 slots. Pinouts from the nine pin connector at each slot are sent through the backplane assembly to the two 25 pin D connectors, J9 and J10, and one nine pin connector, J11. Any monitor voltages to be measured may be done between the chassis ground and the required pin.

The pins are numbered as follows:

Table 13 - 7100M Alarm Connector (J9) Pinouts

Pin No.	Function	Name	Slot No.
1	AGC/RF Alarm	RfAlm1	1
2	AGC/RF Alarm	RfAlm2	2
3	AGC/RF Alarm	RfAlm3	3
4	AGC/RF Alarm	RfAlm4	4
5	AGC/RF Alarm	RfAlm5	5
6	AGC/RF Alarm	RfAlm6	6
7			
8			
9			
10			
11			
12			
13			
14	OPT/LSR Alarm	OptAlm1	1
15	OPT/LSR Alarm	OptAlm2	2
16	OPT/LSR Alarm	OptAlm3	3
17	OPT/LSR Alarm	OptAlm4	4
18	OPT/LSR Alarm	OptAlm5	5
19	OPT/LSR Alarm	OptAlm6	6
20			
21	Relay Standby P.S NOP	R2S	
22	Relay Standby P.S Comm	R1S	
23	Relay Power P.S NOP	R2M	
24	Relay Power P.S Comm	R1M	
25	GND	GND	

Table 14 - 7100M Monitor Connector (J10) Pinout

Pin No.	Function	Name	Slot No.
1	RSSI Monitor	RSSI	1
2	RSSI Monitor	RSSI	2
3	RSSI Monitor	RSSI	3
4	RSSI Monitor	RSSI	4
5	RSSI Monitor	RSSI	5
6	RSSI Monitor	RSSI	6
7	PDI Monitor	PDi1	1
8	PDI Monitor	PDi2	2
9	PDI Monitor	PDi3	3
10	PDI Monitor	PDi4	4
11	PDI Monitor	PDi5	5
12	PDI Monitor	PDi6	6
13	LSRI Monitor	LsrM1	1
14	LSRI Monitor	LsrM2	2
15	LSRI Monitor	LsrM3	3
16	LSRI Monitor	LsrM4	4
17	LSRI Monitor	LsrM5	5
18	LSRI Monitor	LsrM6	6
19			
20			
21			
22			
23			
24			
25	Ground	GND	

Table 15 - 7100M LNB Connector (J11) Pinout

Pin No.	Function	Name	Slot No.
1	LNB Powering	LNB1	1
2	LNB Powering	LNB2	2
3	LNB Powering	LNB3	3
4	LNB Powering	LNB4	4
5	LNB Powering	LNB5	5
6	LNB Powering	LNB6	6
7			
8			
9	GND	GND	



Figure 40 - 7100M Pin Numbers

10.5.1. 7100M and Redundancy Switching

The 2000 Switch provides optional 1:1 redundancy switching for all Foxcom Interfacility Links. If the customer chooses to add redundancy switching to the link, the pin connector jumpers need to be moved. Detailed instructions on moving the jumpers are provided in the *Model 2000 1:1 Redundant Switch Installation and User's Guide (Document Number 93-010-01).*

10.6. The 2300 Relay Adaptor

The following section describes how to install the 2300 Relay Adaptor onto the 7100M Chassis. The 2300 Relay Adaptor assembly provides dry contact outputs as an option to the standard open collector signals available on the 7100M chassis backplane.

If the 2300 Relay Adaptor is ordered separately from the 7100M chassis, it must be mounted by the user. The 2300 is easily mounted directly over the connectors on the 7100M backplane, as shown below.

10.6.1. Installing the 2300 - Parts Needed

- 2300 Relay Adapter
- Two pin guides
- Four one inch screws
- Screw driver

10.6.2. Installing the 2300 - Procedure

To mount to the 2300 Relay Adapter:

WARNING

DO NOT PERFORM THIS PROCEDURE BEFORE DISCONNECTING THE ELECTRICITY

1. Disconnect the electricity.
2. Make sure that you have all the needed equipment.
3. Install the pin guides.



Figure 41 - Mounting the Chassis and Adaptor - Detail

4. Mount the unit onto the pin guides.



Figure 42 - Mounting the Pins and Adaptor

5. Mount the four screws. The screws must be installed in the order shown in Figure 43 and Figure 44.



Figure 43 - Mounting the Screws (1)



Figure 44 - Mounting the Screws (2)

CAUTION

Use only the mounting screws provided by Foxcom. Using other screws can permanently damage the unit!



Figure 45 - Mounted 2300

6. Connect the cables.

10.6.3. 2300 Dimensions and Front Panel Label



Figure 46 - 2300 Dimensions



Figure 47 - 2300 Front Label

10.6.4. 2300 Pinouts

The following table details the 2300 Alarms pinouts.

Table 16 - 2300 Alarms Pinouts (J2)

Pin Number	Function	Name	Slot Number
1	Opt. Alarm	OPTA1	1
2	RF Alarm	RFA1	1
3	Common	COM1	1
4	Opt. Alarm	OPTA2	2
5	RF Alarm	RFA2	2
6	Common	COM2	2
7	Opt. Alarm	OPTA3	3
8	RF Alarm	RFA3	3
9	Common	COM3	3
10	Opt. Alarm	OPTA4	4
11	RF Alarm	RFA4	4
12	Common	COM4	4
13	Opt. Alarm	OPTA5	5
14	RF Alarm	RFA5	5
15	Common	COM5	5
16	Opt. Alarm	OPTA6	6
17	RF Alarm	RFA6	6
18	Common	COM6	6
19			
20			
21			
22			
23	Standby PS Alarm	SPSA	
24	Main PS Alarm	MPSA	
25	Power Supply Comm.	PSCOM	

Table 17 - 2300 Monitor Connector Pinout (J4)

Pin No.	Function	Name	Slot No.
1	RSSI Monitor	RSSI	1
2	RSSI Monitor	RSSI	2
3	RSSI Monitor	RSSI	3
4	RSSI Monitor	RSSI	4
5	RSSI Monitor	RSSI	5
6	RSSI Monitor	RSSI	6
7	PDI Monitor	PDI1	1
8	PDI Monitor	PDI2	2
9	PDI Monitor	PDI3	3
10	PDI Monitor	PDI4	4
11	PDI Monitor	PDI5	5
12	PDI Monitor	PDI6	6
13	LSRI Monitor	LSRI1	1
14	LSRI Monitor	LSRI2	2
15	LSRI Monitor	LSRI3	3
16	LSRI Monitor	LSRI4	4
17	LSRI Monitor	LSRI5	5
18	LSRI Monitor	LSRI6	6
19			
20			
21			
22			
23			
24			
25	Chassis Ground	GND	



Figure 48 - 2300 Pin Numbers

10.7. Changing the Primary Power Setting

By default all 7100M chassis are set operation at 230 VAC. To change to 115 VAC operation the instructions below **must** be followed to avoid damage to both personnel and equipment.

To change the mode:

1. Disconnect the AC power.
2. Unplug the power supply module from the chassis.
3. Place a small screwdriver under the Lip.
4. Gently press upwards; the Fuse Drawer will come out slightly.



Figure 49 - Fuse Drawer



Figure 50 - Voltage Selector (230 Side)

5. Pull the Fuse Drawer out completely; the Voltage Selector is at the top of the compartment. The number on the Voltage Selector is 230.

6. Using the screwdriver, gently remove the Voltage Selector from the Connector.

7. Turn the Voltage Selector so that the number 115 facing outward.



Figure 51 - Voltage Selector (115 Side)

8. **Gently** put the Voltage Selector back into the Connector. The Voltage Selector should snap in easily.

9. Remove the fuse from the fuse drawer, and insert the 1A/250V fuse.
10. Snap in the Fuse Drawer.

If you need to replace the fuse use the parts specified in the following table:

Table 18 - AC Voltage Fuse Part Numbers[21]

Voltage	Current	Littelfuse Part No.	Schurter Part No.
230	0.5 A	239.500	0034.3114
115	1.0 A	239.001	0034.3117

Both fuses are slow-blow 250 VAC rated.

Table 19 - DC Voltage Fuse Part Number[22]

Voltage	Current	Bussman Part No.	Schurter Part No.
220	5 A	S506 GDC-5	0034.3124

The fuse is slow-burn.

[21] or the equivalent

[22] or the equivalent

11. Appendix V Pinouts, Detailed Information

The following charts give detailed information regarding the chassis and 2000 Switch pinouts.



Figure 52 - Standard 7180M and 7180M with 2380 Relay Adaptor Pinout



Figure 53 - 7180M with 2000 Switch Pinout



Figure 54 - Pinout of 7180M Jumper with 2000 Switch in Slot 2 and 5



Figure 55 - Pinout of 7180M Jumper with 2000 Switch in Slot 2



Figure 56 - Pinout of 7180M Jumper with 2000 Switch in Slot 5



Figure 57 - Pinout of 7180M Jumper with Tx or Rx only